



Instruction manual roller elements

NSX – Nordic Slider Cross Country
NSA – Nordic Slider Alpine



- 1) Put Nordic Slider in the gutter upside down.
- 2) Adjust the roller elements exactly horizontal.



- 4) Turn around Nordic Slider again.



- 4a) NSA – Nordic Slider Alpine only:
Put the washers in the recess of the gutter. The washer is asymmetric. The hole has to be on the side of the gutter.

- 4b) Put Nordic Slider in the gutter.



- 3) Fix the roller elements in horizontal position.
Max. torque 25 Nm.



- 5) Fix Nordic Slider with the screws.